

Seç "Kontrolör"

VRF system

File Preference Tool Help Update District : Europe

VRF system Controller Etc Address View Output Menu

Make VRF Sys.

Unregistered list

No	Series	Name	Model	Number of indoor Count

VRF 1		Outdoor	3/100	Indoor	15/400
Outdoor	3	Lon convertor		0	
Indoor	15	Network convertor		1	
RB UNIT	12	etc 登録 - Signal Amplifier		0	

VRF 2		Outdoor	2/100	Indoor	15/128
Outdoor	2	Lon convertor		1	
Indoor	15	Network convertor		0	
RB UNIT	12	etc 登録 - Signal Amplifier		0	

kontrolör ekranı

Controller

File Preference Tool Help Update District : Europe

VRF system Controller Etc Address View Output Menu

Controller

	Controller Name	Abbreviation	Model	Done	Caution	ALL
<input type="radio"/>	System Controller	SC	UTY-APGX	0	0	0
<input type="radio"/>	System Controller Lite	SCL	UTY-ALGX	0	0	0
<input type="radio"/>	Touch Panel Controller	TP	UTY-DTGY	0	0	0
<input type="radio"/>	Touch Panel Controller(internet ac)	TPZ	UTY-DTGYZ1	0	0	0
<input checked="" type="radio"/>	Central Controller	CR	UTY-DCGY	0	0	0
<input type="radio"/>	Group Remote Controller	GR	UTY-CGGY	0	0	0

Select indoor Controller

VRF System	No	Outdoor	OutdoorModel	No	Indoor	IndoorModel	Floor	Room	Comment	Controller
										SC SCL TP TPZ CR GR
1	1	Otdr1	AJY288LALBH	1	Indr1	AUXD18GALH				
				2	Indr2	AUXD18GALH				
				3	Indr3	AUXD18GALH				
				4	Indr4	AUXD18GALH				
				5	Indr5	AUXD18GALH				
				6	Indr6	AUXD18GALH				
				7	Indr7	AUXD18GALH				
				8	Indr8	AUXD18GALH				
				9	Indr9	AUXD18GALH				
				10	Indr10	AUXD18GALH				
				11	Indr11	AUXD18GALH				
				12	Indr12	AUXD18GALH				
				13	Indr13	AUXD18GALH				
				14	Indr14	AUXD18GALH				

## Kontrolör ögesi Liste (2017 Mart itibariyle)

- 1.Sistem kontrolör
- 2.Sistem Kontrolörü Lite
- 3.Touch Panel Denetleyicisi
- 4.Touch Panel Denetleyicisi (internet ac)
- 5.Merkezi Kontrolör
- 6.Group Uzaktan Kumanda


Denetleyici ayar ekranına gidin

Tüm kontrolör koşulları  
Her bir iç mekan tarafından kontrol ünitesi numaralarını onaylayın.

The screenshot shows the 'Controller' software interface. At the top, there is a menu bar with 'File', 'Preference', 'Tool', 'Help', and 'Update'. Below the menu bar, there are several buttons: 'VRF system', 'Controller', 'Etc', 'Address', 'View', 'Output', and 'Menu'. The 'Controller' button is highlighted. Below the buttons, there is a table titled 'Controller' with columns: Controller Name, Abbreviation, Model, Done, Caution, and ALL. The table lists six controller types: System Controller, System Controller Lite, Touch Panel Controller, Touch Panel Controller(internet ac), Central Controller, and Group Remote Controller. The 'Group Remote Controller' is selected. Below this table, there is a 'Select indoor Controller' button. At the bottom, there is a large table titled 'VRF System' with columns: VRF System, No, Outdoor, OutdoorModel, No, Indoor, IndoorModel, Floor, Room, Comment, and a section for Controller (SC, SCL, TP, TPZ, CR, GR). The table shows 14 indoor units connected to a single outdoor unit.

Controller Name	Abbreviation	Model	Done	Caution	ALL
System Controller	SC	UTY-APGX	1	0	1
System Controller Lite	SCL	UTY-ALGX	0	0	0
Touch Panel Controller	TP	UTY-DTGY	2	0	2
Touch Panel Controller(internet ac)	TPZ	UTY-DTGYZ1	0	0	0
Central Controller	CR	UTY-DCGY	0	0	0
Group Remote Controller	GR	UTY-CGGY	1	0	1

VRF System	No	Outdoor	OutdoorModel	No	Indoor	IndoorModel	Floor	Room	Comment	SC	SCL	TP	TPZ	CR	GR
1	1	Otdr1	AJY288LALBH	1	Indr1	AUXD18GALH				1		1			
				2	Indr2	AUXD18GALH				1		1			
				3	Indr3	AUXD18GALH				1		1			
				4	Indr4	AUXD18GALH				1		1			
				5	Indr5	AUXD18GALH				1		1			
				6	Indr6	AUXD18GALH				1		1			
				7	Indr7	AUXD18GALH				1		1			
				8	Indr8	AUXD18GALH				1		1			
				9	Indr9	AUXD18GALH				1		1			
				10	Indr10	AUXD18GALH				1		1			
				11	Indr11	AUXD18GALH				1		1			
				12	Indr12	AUXD18GALH				1		1			
				13	Indr13	AUXD18GALH				1		1			
				14	Indr14	AUXD18GALH				1		1			



Sistem Kontrolörü koşulu

Kayıt birimlerinin gösterilmemiştir  
Kayıtlı VRF Sistemleri değil gösterilen tarafından kontrol etme


Ekleme Sistem Kontrolörü

Sistem Kontrolörü Sil

Sistem Denetleyici listesi ve seçeneği ekleyin  
Opsiyon kontrol ederek ilave edilir  
ikon renk : Normal  
Simge rengi : Uyarı  
ikon renk : Hata


Kayıtsız ünite liste

Kayıtlı birim listesi



Soğutucu sistemler ve kontrol etmek için iç ünite her bir seçilebilir

# kontrolör-Dokunma Panel denetleyici, merkezi kontrol Kontrol tasarım



VRF Sistemi seç

Dokunmatik / Merkez Kontrolörü koşulu

Kayıt birimlerinin gösterilmemiştir

Ekleme Dokunma / Merkez Kontrolörü

Dokunmatik / Merkezi Kontrol Sil

Dokunmatik / Merkez Kontrolörü listesi ve seçeneği ekleyin

Opsiyon kontrol ederek ilave edilir

ikon renk : Normal


Simge rengi : Uyarı

ikon renk : Hata

Kayıtsız ünite liste

Soğutucu gaz sistemleri ve iç üniteler her birine kaydedilebilir

Kayıtlı birim listesi



VRF Sistemi seç

Grup Uzaktan kumanda ayar koşulu

Kayıtlı birimler gösterilmemiştir

Grup ekle uzak kontrolör seti

Grup Uzaktan kumanda ayar silme

Grup Uzaktan kumanda set listesi  
Grup Uzaktan Kumanda kontrol ederek ilave edilir  
ikon renk : Normal  
Simge rengi : Uyarı  
ikon renk : Hata

Kayıtsız ünite liste  
Soğutucu gaz sistemleri ve iç üniteler her birine kaydedilebilir

Kayıtlı birim listesi